



KILLER PRODUCTS  
INGERSLEVSGADE 130, 4. sal, tv / 1705 COPENHAGEN V  
WWW.KILLER-PRODUCTS.DK

TEL: +45 60350036  
INFO@KILLER-PRODUCTS.DK

## Hood Frame Nuts for VW 181 “Thing” Installation Instructions

### Please check that the package contains the following:

- 1 Pc. Bottle of locking glue
- 1 Pc. Hex key
- 8 Pcs. Stainless steel special nuts
- 8 Pcs. Stainless steel bolts
- 8 Pcs. Large stainless steel washers
- 8 Pcs. Polyamide washers PA 6

### Installation

Drill out the old rivets - use a 27/64" drill bit and hold the back with some flat faced vice grips.  
If necessary, paint your frame. We recommend powdercoating the frame.

After painting the frame, the holes may be to small. Make sure that the nuts fit into all the holes before assembly.

Mount the parts as shown in the illustration below. (It's easiest to assembly the frame on a flat surface)  
Remember to put the locking glue onto the bolt. Make sure you tighten the bolts good.

After you have assembled the hood frame, the locking glue has to dry for a couple of hours.

